TROLLEY ACCESSORIES

Trolley Lock Starter Chain

The starter chain fixed at the trolley park that secures the first trolley in a line of coin-lock trolleys.



Product code **30646715** | Fits **Coin trolley locks**

1	£1	Durable	Trolley
per line	coin locks	chain	park

Overview

The starter chain is fixed at the trolley return point and secures the first trolley in the line.

When customers return a trolley, they connect it to the line and their coin is released. Having a set place to return trolleys reduces losses.

Key features

- **Anchors the first trolley** in each line
- **Works with coin locks** releases the deposit
- **Fixes to trolley parks** and shelters
- **Durable construction** for daily use
- **Fits** our wire trolley range

Specification

Product code	30646715
Specification	
Use	Fixed to a trolley park or shelter
Works with	£1 coin trolley locks
Note	Not the chain fitted to each trolley lock

Store Fittings Direct is a trading name of CHF Solutions Ltd, registered in England & Wales 12316756. Specification may change without notice. © 2026 Store Fittings Direct. Not to be copied or reproduced without permission.

Scan to view online

Where it is used

Trolley parks and shelters at supermarkets, retail parks and shopping centres.

How many?

Order one starter chain for each line of trolleys at the trolley park.

store fittings direct

Talk to someone who sells this every day

Tell us about your store size and how many customers you serve, and we will help you choose the right trolleys.

Call 0116 318 4182

Store Fittings Direct is a trading name of CHF Solutions Ltd, registered in England & Wales 12316756. Specification may change without notice. © 2026 Store Fittings Direct. Not to be copied or reproduced without permission.

Scan to view online